

Operation Instructions

Make your choice...

M-206 Card & Password Access Keypad




1 Safety Instruction

 Thank you for your purchasing, please read this manual before use it.

2 Overall Characteristics

- Specialized for office building, residential, security system, and other entrance&exit access control system
- With the standard capacity of the user records of 1000pcs.
- Opening method: card, password and both.
- Durable and pretty, all data will not be lost due to power off.
- Easy and simple to operate, flexible to add and delete the cards.
- Can be directly connected to the automatic door to realize the coordination function of unlocking first and then opening the door.

3 Wiring Diagram



4 Technical Parameters

Power voltage: DC 12V
Unlocking current: <1000mA
Static current: <60mA
Storage capacity: 1000 pcs users
Reading card distance: 5-20cm
User card type: EM or EM compatible card
Working temperature: -10°C~70°C
Working humidity: 10%~90%
Dimension: 117(L)x117(W)x21(H)mm

5 Operation Process

Operation name	Continuously Operating				Operating result	Remark	
	System password	Function	Operate	Exit			
Revise system password	#12345	1	88888(sample)	*	System password is 88888	System password is 5-digit	
Revise opening password	#12345	2	2580(sample)	*	Opening password is 2580	Opening password is 4-digit	Commonly used
Set door opening ways	#12345	3	01	*	Card or password all can open the door	00-swipe card for opening; 01-card or password; 02-card + password	
Add card (enter single card No.)	#12345	4	0# card No.#	*	This card No. have been entered	Card No. refers to the last 8 digits of previous number group of the inkjet number	
Add card (swipe card continuously)	#12345	4	1# swipe card#	*	All the cards that were swiped have been added	Swipe multiple cards continuously	Commonly used
Add card (card No. in batches)	#12345	5	0# card No.# qty of card# (beep voice)	*	A total of a specified number of cards have been added from initial card No. (consecutive No.)	The qty of card must be 3-digit, and when beep voice is finished then push "*" to exit	
Add card (swipe card in batches)	#12345	5	1# swipe card enter qty of card# (beep voice)	*	A total of a specified number of cards have been added from initial card No. (consecutive No.)	The qty of card must be 3-digit, and when beep voice is finished then push "*" to exit	
Delete card (enter single card No.)	#12345	6	0#card No.#	*	This card No. have been deleted	Card No. refers to the last 8 digits of previous number group of the inkjet number	
Delete card (swipe card continuously)	#12345	6	1# swipe card#	*	All the cards that were swiped have been deleted	Swipe multiple cards continuously	Commonly used
Delete card (card No. in batches)	#12345	7	0# card No.# qty of card#	*	A total of a specified number of cards have been deleted from initial card No. (consecutive No.)	The card No. must be consecutive No. and the qty of card must be 3-digit	
Delete card (swipe card in batches)	#12345	7	1# swipe card enter qty of card#	*	A total of a specified number of cards have been deleted from initial card No. (consecutive No.)	The card No. must be consecutive No. and the qty of card must be 3-digit	
Delete all cards	#12345	8	88# (long beep voice)	*	All user cards have been deleted	After long beep voice, all user cards are deleted	
Revise door opening time	#12345	0	05(2-digit seconds)	*	Door opening time is revised to 5 seconds	From 01 to 99 seconds	Commonly used
System initialization	Power off, open the back cover, find black pin cap, connect feet 2 and 3 of the S16.		→ Repower, continuous beep voice, 3 indicator lights flashes	→	Power off, connect feet 1 and 2 of the S16.	→ After the buzzer sounds, the initialization succeeds, enters the user status.	→ System password is restored to 12345, other data don't have to delete.

Note: The default setting of system password is 12345. If you hear 4 beep alarms after entering 12345, means default setting has been changed already. Initialization setting can restore the default password.